

SAFE-HIT®

KonaPost® Placement Instructions

For Asphalt or Concrete

IT IS THE RESPONSIBILITY OF THE INSTALLER TO MAINTAIN A SAFE WORK AREA INCLUDING THE USE OF STANDARD WORK ZONE SAFETY EQUIPMENT & PPE: GLOVES, SAFETY-TOE SHOES, EYE & EAR PROTECTION

- 1: Check that you have all the parts necessary for KonaPost® deployment. KonaPost®, Anchors and adhesive kits are required for each installation. One 4 oz adhesive kit (PN 604885) is required for each KonaPost® anchor. Larger adhesive kits are available upon request.



- 2: Locate and drill 1 3/4" diameter x 8 1/4" deep hole per site plan.



- 3: Blow out hole with compressed air to remove all debris. A clean, dry surface is required inside hole and within a 4" diameter outside the hole.

- 4: Mix equal amounts of Part "A" and Part "B" adhesive.

Note: Do not apply adhesive when the ambient temperature is below 41°F (5°C) or above 104°F (40°C). The adhesive is easiest to work with if warmed to approximately 80°F (26°C).



- 5: Apply a generous amount of adhesive to outside diameter and the underside of top plate of the KonaPost® Anchor (PN 603667).



- 6: Insert the KonaPost® Anchor into the hole and press down firmly on the top plate until a bead of adhesive appears around the edge.

Consult OSHA respiratory standards for crystalline silica exposure.



- 7: Allow adhesive to set before KonaPost® placement (PN SHLG19GPR--_ _).

Adhesive Set Times	
Base Material Temperature	Set Time
90°F	2 HOURS
70° F	4 HOURS
50° F	7 HOURS