

SAFE-HIT®

Safe-Hit® SQR-LOC™ Flexible Delineator Placement Instructions

TOOLS & MATERIALS

- 2" x 2" x 24", 12GA. Perforated Galvanized Steel Anchor
- Manual or Powered Driver Tool
- Drive Adaptor for 2"x 2" Square Signpost Anchor
- Safe-Hit® SQR-LOC™ Flexible Delineator
- Safe-Hit® SQR-LOC™ Protective Collar
- 3/8" x 3" Steel Pin

Important: MANUALS AND POWER TOOLS ARE NOT PROVIDED. FOLLOW ALL SAFETY PRECAUTIONS AS DESCRIBED IN THE OWNER'S MANUAL OF THE USER SUPPLIED EQUIPMENT.



Step 1: Install the anchor so that the top sticks out of the ground 2". Position the anchor so that a flat face is in the direction of traffic. Leave at least the top 4" inside the tube free from soil and debris.



BOTTOM OF DELINEATOR

Step 2: Place the protective collar onto the delineator as shown.



Step 3: Place the square formed end of the delineator into the anchor and align the hole in the delineator with the hole second from the top in the anchor. Use the holes that are perpendicular to the direction of traffic.



Step 4: Insert the 3/8" x 3" steel roll pin into the second hole from the top. Position it so that equal lengths of the pin stick out from each end.



Step 5: Slide the protective collar onto the anchor. Ensure that the corners of the protective collar are in line with the corners of the anchor. The protective collar should press into place with hand pressure, but sometimes a gentle tap with a mallet is necessary to set it in place. Ensure that the lower surface of the collar rests on the ground.



Assembled delineator

IT IS THE RESPONSIBILITY OF THE INSTALLER TO MAINTAIN A SAFE WORK AREA INCLUDING THE USE OF STANDARD WORK ZONE SAFETY EQUIPMENT & PPE: GLOVES, SAFETY-TOE SHOES, EYE & EAR PROTECTION