

SAFE-HIT®

Safe-Hit® SQR-LOC™ ADOT Version Flexible Delineator Placement Instructions

MATERIALS PROVIDED

- 2" x 2" x 24", 12GA. Perforated Galvanized Steel Anchor
- Safe-Hit® SQR-LOC™ ADOT Version Flexible Delineator
- 3/8" Clevis Pin with Cotter Hair Pin

REQUIRED TOOLS

- Manual or Powered Driver Tool
 - Drive Adaptor for 2"x 2" Square Signpost Anchor
- MANUAL AND POWER DRIVER TOOLS ARE NOT PROVIDED. FOLLOW ALL SAFETY PRECAUTIONS AS DESCRIBED IN THE OWNER'S MANUAL OF THE USER SUPPLIED EQUIPMENT.**



Step 1: Position the anchor so that a flat face is in the direction of traffic. Install the anchor so that the top sticks out of the ground approximately 2" to ensure the second hole from the top of the anchor is accessible. Leave at least the top 4" inside the tube free from soil and debris.



DELINEATOR BOTTOM

Orientation of the Anchor and the Delineator must comply with the project plans or as otherwise determined by the project engineer or appropriate highway authority.



Step 2: Place the square formed end of the delineator into the anchor and align the hole in the delineator with the hole second from the top in the anchor. Use the holes that are perpendicular to the direction of traffic.



Step 3: Insert the 3/8" clevis pin into the second hole from the top. Secure the clevis pin with a cotter hair pin.

Note: Clevis pin is perpendicular to traffic.



ASSEMBLED DELINEATOR

IT IS THE RESPONSIBILITY OF THE INSTALLER TO MAINTAIN A SAFE WORK AREA INCLUDING THE USE OF STANDARD WORK ZONE SAFETY EQUIPMENT & PPE: GLOVES, SAFETY-TOE SHOES, EYE & EAR PROTECTION